# **SmartCharge**

Automatic Battery Charger

DS-400/1

500-LC MAS 2024R 24V-20A



**SmartCharge** Automatic battery chargers provide a cost effective solution to most industrial battery charging requirements.

Utilising the latest high efficiency switch-mode technology and micro-processor control, the SmartCharge 500-LC is suitable for charging most sealed or flooded batteries and is easily calibrated by the end user to suit the battery type. The multi-stage intelligent charging characteristic ensures accurate and efficient battery charging and is designed for permanent connection to the batteries maintaining them in a fully charged condition without overcharging.

The SmartCharge 500-LC is fully protected against overload, reverse battery connection, over voltage and over temperature.

#### **INPUT SPECIFICATION**

Voltage range, V <sub>IN</sub>	100 - 264V AC
Frequency	47 - 63Hz
Input current	5.5A max.
Leakage current	<2mA / 240VAC

#### **OUTPUT SPECIFICATION**

Voltage / Current	24.0V Nominal 20A. Other voltages on request
Ripple and noise	±0.5%
Line regulation	±0.5%
Load regulation	±1.0%
Efficiency	Up to 92%
Overload protection	Constant current limit
Over temp. protection	Output shutdown with automatic recovery
Reversed battery protection	Automatic protection. Disabled when in PSU mode.

# **ALARMS AND LEVELS**

DC output voltages	Float = Factory set to 27.6V. Boost (Bulk/Absorb) = Float Voltage +4%.
AC / charger fail	Loss of AC input or DC output voltage control
Low DC voltage alarm	Float voltage -12% alarm, -8% Reset
High DC voltage alarm	Float voltage +7% alarm, +5% Reset
Over voltage protection	30.5 Instantaneous lockout
Battery disconnected	Open circuit on DC output (Disabled in PSU mode)

#### **FEATURES**

- Cost effective
- · Micro-processor control
- · Small footrint & compact size
- · Din rail mounting
- · Automatic multi-stage charging
- Manual boost override
- · Continously rated
- Protections
  - Short circuit and overload
  - Over voltage
  - Over temperature
  - Reverse battery
- · Universal AC input range
- · Low ripple output
- Naturally cooled
- Simple calibration procedure
- · Comprehensive alarm monitoring
- · Fail alarm contact set

#### **APPLICATIONS**

- Standby & prime power generators
- Engine driven pumps and compressors
- Switch gear tripping
- · Industrial control systems
- Robust PSU
- Alarm systems
- Navigational aids



# **SmartCharge**

#### **ISOLATION**

Withstand voltage	Input - Output, Input - Earth 1.5kV AC
Isolation resistance	Input - Output, Input - Earth, Output - Earth 500V DC / 100M Ohms

#### **ENVIRONMENTAL SPECIFICATION**

Working temperature	-10°C to +50°C
Working humidity	20 - 90% RH
Storage temperature	-20°C to +85°C
Storage humidity	10 - 95% RH
Unpacked weight	1.7 kgs

# **FINISH**

Aluminium / RAL9005 black fine texture

# **FAIL ALARM RELAY CONTACT SET (OPTIONAL)**

Volt-free form C relay contact set for signalling of a fault alarm condition. The relay contacts de-energise 60 seconds after a fault occurs. The over voltage protection shutdown alarm de-energises the contacts instantly.

# **TERMINATION**

#### AC input and DC output:

Connections terminate to rising clamp screw terminals and will accept 6.0mm<sup>2</sup> stranded cable.

#### Optional fail alarm:

Connections terminate to rising clamp screw terminals and will accept 2.5mm<sup>2</sup> stranded cable.

#### Connector 'C1' (signals):

Pins 7 and 8 should be linked when the charger should also function as a PSU.


NOTE: Reverse battery and battery disconnected alarms are disabled in PSU mode.


The remaining pins are for expansion modules, communication interfaces, firmware upgrade, etc and should not be used.


#### **ORDERING INFORMATION**

Model No.	DC output
MAS 2024R 24V-20A	24V 20A

# **GENERAL ARRANGEMENT**









Top-hat din rail mount

Optional brackets for screw fixing

- DISCONNECT THE BATTERY.
  CONNECT A DC VOLTMETER TO THE
  Z. TURN THE TOAL POTENTIONETER FOR
  WHEN THE STATUS LED FLASHES OF
- TURN THE "CAL" POTENTIOMETER FULLY ANTI-CLOCKWISE.
   WHEN THE STATUS LED FLASHES GREEN/RED 8 5Hz. ADJUST 1
- POTENTIONETER AND SET THE DESIRED FLOAT VOLTAGE LEVEL.

  3. WHEN THE LED RED/GREEN @SHZ FLASH SEQUENCE ENDS THE UNIT
- IS CALIBRATE

